



FEATURES

- Gamma & neutron independent channels
- Very high sensitivity and fast response
- Relative thresholds to background
- Real time rejection of sudden background variation (VBS Algorithm)
- Automated spectra acquisition on alert and identification (NMD algorithm)
- Clear discrimination of risk category
- Visual and audible alarms
- Wireless communication interface
- Designed to meet/exceed ITRAP and ANSI standards

HDS-100G/GN

Handheld Search and Identification

HDS-100G/GN are handheld devices designed to search for radioactive materials and to respond to radiological threats such as illicit trafficking and RDDs.

They are able to identify radionuclides and classify them as medical, industrial, natural occurring radioactive materials (NORM) and special nuclear materials (SNM).

They can be used to detect, localize and characterize threats during surveys or to complement with detection portal.

The HDS-100G/GN are ideally suited for First Responders, Border & Customs inspectors, Site Security in critical infrastructures, and for all applications related to the control of radioactive and nuclear materials.

VERSIONS:

- HDS-100G: gamma version
- HDS-100GN: gamma and neutron version

health physics

A Mirion Technologies Division

Featuring:



NUCLEAR CHARACTERISTICS

- **Detectors:**
 - Low gamma scintillator CsI(Tl)
 - High gamma : silicon diode
 - Neutron LiI (Eu)
- **Energy range:**
 - 30 keV to 3 MeV (gamma)
 - 0.025 eV to 15 MeV (neutron)
- **Measurement and identification range (gamma):**
 - 0.01 μ Sv/h to 100 μ Sv/h (1 μ rem/h to 10 mrem/h)
- **Extended gamma range:**
 - Continuous: 0.1 mSv/h to 10 mSv/h, 10 mrem/h to 1 rem/h
 - Temporarily: up to 10 Sv/h (1000 rem/h)



ALGORITHM PROCESSING

- Continuous spectra acquisition and stabilization (0.2s time slot)
- Continuous dose rate and count rate comparison to background
- Varying Background Suppression algorithm (VBS) continuously analyses the spectra shape and rejects alerts due to sudden background changes
- NORM Medical Discrimination algorithm (NMD) categorizes and identifies up to 4 simultaneous isotopes

NORM:	40K, 226Ra and daughters, 232Th and daughters
Medical:	18F, 51Cr, 67Ga, 75Se, 99mTc, 111In, 123I, 131I, 201Tl
Industrial:	22Na, 57Co, 60Co, 133Ba, 137Cs, 152Eu, 192Ir, 241Am
SNM:	235U, 238U, 239Pu

- Cumulated spectra can be triggered by alert detection or on request

FUNCTIONAL FEATURES



- Three modes: detection, search and integration
- Three users profile: routine, expert, custom
- Alert threshold configurable for dose rate and/or number of sigma level increase
- Safety alarm
- Pre-loaded languages
- Historical record with more than 1000 events/measurements and 60 spectra
- Bluetooth®, RS232 and USB interfaces
- Audio output for earphone
- Designed to meet/exceed ANSI 42-33, Type I & II and to IAEA standards

ELECTRICAL & MECHANICAL CHARACTERISTICS

- Power supply: 6 x AA batteries (Ni-MH rechargeable), built-in charger
- Battery life time: 30 hours typical
- Dimensions (l x Ø): 280 x 78 mm (11 x 3.1 in)
- Weight: 1500 g (52.9 oz)

ENVIRONMENTAL CHARACTERISTICS

- Temperature range: -20°C to 50°C (-4°F to 122°F)
- Humidity: < 90% at 42°C (108°F)
- EMI, shock, vibration and drop resistant
- Water protection (IP54)
- CE compliant

ACCESSORIES

- Shoulder strap
- USB cable
- Transportation case
- HDSMASS and SMI software
- Power supply/charger/wall-mount charger



HDSMass software spectra



Mirion Technologies (MGPI) Inc
5000 Highlands Parkway
Suite 150
Smyrna Georgia 30082
USA
T +1.770.432.2744
F +1.770.432.9179

Mirion Technologies (MGPI) SA
BP 1
F-13113 Lamanon
France
T +33 (0) 4 90 59 59 59
F +33 (0) 4 90 59 55 18

Mirion Technologies (RADOS) Oy
P.O. Box 506
FIN-20101 Turku
Finland
T +358 2 468 4600
F +358 2 468 4601

Mirion Technologies (RADOS) GmbH
Ruhrstrasse 49
DE-22761 Hamburg
Germany
T +49 (0) 40 851 93-0
F +49 (0) 40 851 93 256

www.mirion.com
144211EN-B